

Nuendo / DM2000 Setup and Operation – V2

This document describes setup and operation for remote control of Nuendo from the DM2000 digital mixing console. These instructions apply to DM2000 V2.0 or higher and Nuendo V2.20 or higher.

Driver Installation

- 1) Connect your PC or Macintosh computer
The DM2000 should be connected to your computer by connecting the TO HOST USB port on the DM2000 to a USB port on your computer.
- 2) Install Driver
Once your computer is connected, you will need to install the USB-MIDI driver included on the DM2000 CD-ROM. The latest driver can also be downloaded from www.yamahaproaudio.com

Configuring DM2000 V2

- 1) Press the [SETUP] display access key and select the MIDI/TO HOST screen.
- 2) Set the DAW port assignment to USB 1-4, or set this parameter to USB 2-5 if you will also be using the Studio Manager DM2000 Editor software. Note: you must use USB ports 2-5 for DAW Control and USB port 1 for Studio Manager if you intend to use these two applications simultaneously.
- 3) Press the [REMOTE] display access key and assign NUENDO as the Target for one of the Remote layers.
See “Assigning Targets to Remote Layers” in the DM2000 manual for more information.
- 4) Press the [LOCATOR] display access key and select DAW Control as the function for the transport and locate keys. This allows the Nuendo transport to be controlled regardless of whether a Remote or Internal mixing layer is active.
- 5) Press the relevant [REMOTE] LAYER button to select the Nuendo Remote Control Layer.
When the Nuendo Remote Control Layer is selected, the DM2000’s control surface controls Nuendo rather than the internal mixing of the DM2000. In order to control the DM2000, you need to select an Input Channel Layer or the Master Layer. Audio mixing on the Input and Master Layers, and Automix continues while the Nuendo Layer is selected.

Configuring Nuendo V2.2.0 or higher for Windows

- 1) Click on the 'Devices' menu and select 'Device Setup'.
- 2) Click on the 'Add/Remove' tab, then highlight 'Yamaha DM2000 V2' and click 'Add'. This will cause Yamaha DM2000 V2 to appear in the Devices column on the left side of this window.
- 3) Click on the 'Setup' tab. Highlight 'Yamaha DM2000 V2' in the left column, and select the correct MIDI input from the drop-down menu. For example, if you have chosen USB 1-4 as the DAW port on DM2000 V2, select 'YAMAHA USB 0-1' from the drop down menu for MIDI input. If you have chosen USB 2-5 on DM2000 V2, choose 'YAMAHA USB 0-2'. Then select the same port number for MIDI output. After making these selections, the other USB ports are automatically assigned. Nuendo remote control from DM2000 V2 uses a total of four USB-MIDI ports.
- 4) In the grid below the MIDI port assignments, the functions of various USER DEFINED keys on the DM2000 can be assigned. Some USER DEFINED keys have permanent assignments so they are not available in this list. These functions are described later in this document.
- 5) After completing these assignments, click 'Apply' towards the bottom of the Device Setup window. Then click 'OK' to exit this window.

Configuring Nuendo V2.2.0 or higher for Mac OS X

- 1) Click on the 'Devices' menu and select 'Device Setup'.
- 2) Click on the 'Add/Remove' tab, then highlight 'Yamaha DM2000 V2' and click 'Add'. This will cause Yamaha DM2000 V2 to appear in the Devices column on the left side of this window.
- 3) Click on the 'Setup' tab. Highlight 'Yamaha DM2000 V2' in the left column, and select the correct MIDI input from the drop-down menu. For example, if you have chosen USB 1-4 as the DAW port on DM2000 V2, select 'YAMAHA DM2000 Port 1' from the drop down menu for MIDI input. If you have chosen USB 2-5 on DM2000 V2, choose 'YAMAHA DM2000 Port 2'. Then select the same port number for MIDI output. After making these selections, the other USB ports are automatically assigned. Nuendo remote control from DM2000 V2 uses a total of four USB-MIDI ports.
- 4) In the grid below the MIDI port assignments, the functions of various USER DEFINED keys on the DM2000 can be assigned. Some USER DEFINED keys

have permanent assignments so they are not available in this list. These functions are described later in this document.

- 5) After completing these assignments, click 'Apply' towards the bottom of the Device Setup window. Then click 'OK' to exit this window.

Controlling Nuendo

Input Channel Controls

Faders 1-24 control the levels of Nuendo channels 1-24.

(Refer to the User Defined Keys description below for information about accessing Nuendo channels beyond 1-24.)

The first four characters of the names of the Nuendo channels appear in the Fluorescent channel strip display. Also PAN position is displayed here and can be adjusted with the channels' rotary encoders. DM2000's ON switches control Nuendo's channel MUTEs and the SOLO and SEL switches also control Nuendo's corresponding functions. The AUTO switches on DM2000 control Nuendo's Automation Read function.

For surround panning, pressing the PAN ENCODER MODE switch alternates the function of the encoder between Left-Right and Front-Back panning. When the encoder is functioning in PAN mode, pushing the encoder will activate the MONITOR switch in Nuendo.

By changing the DM2000's ENCODER MODE to AUX/MTRX, Nuendo's SENDS can be controlled. Sends 1-8 can be selected with the DM2000's AUX SELECT switches. Then turning the channel rotary encoders will adjust the send level, with the level shown in the fluorescent display section. In this mode, each send can be switched On/Off by pressing the encoder.

Selected Channel Functions

Pressing any of the DISPLAY switches in the SELECTED CHANNEL section of DM2000 will cause the VST Audio Channel Settings window to open in Nuendo.

COPY & PASTE

The CHANNEL COPY and PASTE switches on DM2000 perform the same functions as COPY and PASTE in Nuendo's Edit menu.

EQ

The four bands of EQ GAIN, FREQUENCY and Q on DM2000 control the same functions on the selected Nuendo channel, and the parameter value is displayed on the

Nuendo / DM2000 Setup and Operation – V2

Page 4

console. To switch an EQ band On or Off, hold down the FREQUENCY/Q encoder for one second.

PANNING

The PAN encoder and the JOYSTICK on DM2000 control the pan functions of Nuendo. Even if there is no surround panning enabled, the joystick can be used for Left-Right panning.

AUX SENDS

The AUX SEND LEVEL encoders and ON switches edit the 8 sends in Nuendo. So only the first two BANKS on DM2000 are used. By pressing the LEVEL encoders, the send can be switched between Pre and Post Fader.

PHASE AND INSERT

The PHASE switch on DM2000 switches the phase of the selected Nuendo channel, and the INSERT ON switch bypasses all Inserts for the selected channel.

LCD Screen & Insert Editing

Press the INTERNAL EFFECTS key on DM2000 to see FX Send information on the DM2000 LCD screen. The encoders below the screen can edit various functions.

- Encoder 1 edits the send level.
- Encoder 2 edits the send On/Off status.
- Encoder 3 switches between Pre and Post Fader.
- Pressing any of the encoders will switch all sends On/Off.

There are 8 sends spread over 8 pages. To access different sends, EFFECTS switches 4 and 8 are used to change pages up and down.

Pressing the EFFECTS DISPLAY switch will switch the LCD screen between showing parameter values or parameter names.

Press the PLUG-INS switch to see Routing information on the LCD. There are two pages, accessed by pressing EFFECTS switch 4 and 8.

Page 1

- Encoder 1 chooses the Output Bus for the selected channel
- Encoder 2 switches the Monitor On/Off (by pressing or turning the encoder)
- Encoder 3 selects the Input bus
- Encoder 4 edits the Input Gain (the encoder must be pressed down while turning)

Page 2

- Only Encoder 1 has a function. It is used to switch the Input Phase On/Off (by pressing or turning the encoder).

When the CHANNEL INSERTS switch is pressed on DM2000, the LCD shows Insert information for the selected channel.

- Encoder 1 selects which insert is to be edited
- Encoder 2 switches the insert On/Off (by turning, not pressing)
- Encoder 3 selects the type of effect to insert

Once an Effect has been selected, all the parameters can be edited by changing the page viewed on the LCD (by using the EFFECT 4 and 8 switches as page Up/Down). The number of pages available depends on the number of parameters used by the Effect. The EFFECT DISPLAY switch toggles between showing the parameter names and the parameter values on the LCD.

Transport & Automation

Ensure that DAW CONTROL is selected in the LOCATE MEMORY screen of the LOCATOR display menu on DM2000.

TRANSPORT CONTROLS

The following Transport functions can be controlled from DM2000:

- REC
- PLAY
- STOP
- FF
- REW
- SCRUB
- LOOP
- QUICK PUNCH
- ONLINE

LOCATE FUNCTIONS

The following DM2000 locate functions also control the corresponding Nuendo functions:

- RTZ
- END
- IN
- OUT
- SET
- LOCATE 1-8

Nuendo / DM2000 Setup and Operation – V2

Page 6

To set a locate point (Marker in Nuendo), hold the SET switch on DM2000, and press the required LOCATE MEMORY switch at the required time. Note: DM2000 must be in the appropriate Nuendo Remote Layer in order to set Markers.

TRACK-ARMING

The DM2000 TRACK ARMING 1-24 switches control the RECORD ENABLE switches of the corresponding NUENDO channels.

AUTOMATION

The following AUTOMIX switches on DM2000 control automation functions of Nuendo:

- ENABLE puts all Nuendo channels into READ mode
- REC puts all Nuendo channels into WRITE mode.
- The AUTO switch above each DM2000 channel fader switches READ On/Off for each channel individually. However, when AUTO-REC is switched on, the channel AUTO switches function to control WRITE On/Off in Nuendo.

User Defined Keys

When DM2000 is used to remotely control Nuendo, the following User Defined Keys have permanently assigned functions:

- UDEF 1: Brings the Project window to the front
- UDEF 2: Scrolls channels down in banks of 8
- UDEF 3: Scrolls channels up in banks of 8
- UDEF 9: Open or closes the VST Mixer window
- UDEF 10: Scrolls channels down one channel at a time
- UDEF 11: Scrolls channels up one channel at a time

Other User Defined Keys (UDEF 4-8 and 12-16) can be programmed by the user to control various Nuendo functions. These functions can be selected in the DEVICE SETUP of Nuendo, by selecting “YAMAHA DM2000 V2” and choosing the Setup tab.

Other Functions

ZOOM & NAVIGATION

The DM2000 CURSOR keys (next to the Scrub Wheel) have two different functions. Their mode can be changed by pressing the INC key above the cursor keys. The mode is shown on the LCD display.

- ZOOM mode: the cursor keys control the vertical and horizontal zoom of the Project Window.

Nuendo / DM2000 Setup and Operation – V2

Page 7

- NAVIGATION mode: the cursor keys control the selection of channels and objects in the Project Window.

TIME COUNTER

The TIME COUNTER is displayed on the DM2000 LCD screen, with the counter mode (TIME CODE / FEET / BEATS). If “Samples” is selected in Nuendo, then no selection is displayed in the DM2000 LCD.

METER BRIDGE

The DM2000 meter bridge displays Nuendo’s input channel levels when the correct REMOTE layer is selected. The TIME CODE counter is also displayed on the Meter Bridge.